


Oscillating

Reflective Carbon Heater with Remote Control & Ionizer

OWNER'S MANUAL

Model: AH-320E



PLEASE SAVE THESE INSTRUCTIONS


WARNING: READ THIS OWNER'S MANUAL CAREFULLY BEFORE USE.

IMPORTANT INSTRUCTIONS

When using this electric unit, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read ALL instructions before using this unit.
2. CAUTION: Risk of Electric Shock. DO NOT open or try to repair the heater yourself.
3. This heater is hot when in use. To avoid burns, DO NOT let bare skin touch hot surfaces. If provided, use handles when moving this heater.
4. Keep combustible materials, such as furniture, pillows, bedding, paper, clothes, and curtains at least 3 ft from the front of the heater and keep them away from the sides and rear. DO NOT place towels or other objects on the heater.
5. Extreme caution is necessary when any heater is used by or near children or the disabled, or when the heater is left operating and unattended.
6. DO NOT operate any heater with a damaged cord or after the heater malfunctions, has been dropped or damaged in any manner. Return heater to authorized service facility for examination, electrical or mechanical adjustment, or repair.
7. This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. NEVER locate heater where it may fall into a bathtub or other water container. To protect against electrical hazards, DO NOT immerse in water or other liquids.
8. DO NOT touch the control panel or plug with a wet hand.
9. DO NOT run cord under carpeting. DO NOT cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
10. DO NOT insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
11. To prevent a possible fire, DO NOT block air intakes or exhaust in any manner. DO NOT use on soft surfaces, like a bed, where openings may become blocked.
12. A heater has hot and arcing or sparking parts inside. DO NOT use in areas where gasoline, paint, explosive and/or flammable liquids are used or stored. Keep unit away from heated surfaces and open flames.
13. Avoid the use of an extension cord because the extension cord may overheat and cause a risk of fire. However, if you have to use an extension cord, the cord shall be No. 16 AWG minimum size and rated not less than 1250W.
14. To avoid fire or shock hazard, plug the unit directly into a 120 V AC electrical outlet.
15. To disconnect heater, turn controls to OFF, then remove plug from outlet. Pull firmly on the plug, DO NOT unplug by pulling on the cord.
16. Always unplug the unit before moving or cleaning, or whenever the heater is not in use.
17. Use only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. The use of attachments not recommended or sold by unauthorized dealers may cause hazards.
18. Always use on a dry, level surface.
19. DO NOT use outdoors.
20. WARNING: To reduce the risk of fire or electric shock, DO NOT use this unit with any solid-state speed control device.

21. DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. Qualified personnel should perform all servicing only.
22. Connect to properly grounded outlets only.
- 23.SAVE THESE INSTRUCTIONS.**



The diagram illustrates three methods of connecting a grounded plug to a two-slot receptacle. (A) shows a standard grounded plug with a grounding pin. (B) shows a plug connected to a two-slot receptacle with a metal screw on the outlet box cover. (C) shows an adapter connected to a two-slot receptacle with a grounding means.

WARNING: This heater is for use on 120 volts. The cord has a plug as shown in A. An adapter as shown in C is available for connecting three-blade grounding-type plugs to two-slot receptacles. The grounding lug extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box. The adapter should not be used if a three-slot grounded receptacle is available.

DO NOT DEFEAT THE SAFETY PURPOSE OF THE GROUNDED PLUG.

PRODUCT INFORMATION


Reflective heating technology replicates the sun's healthy rays, directly warming the object or person in front of the heater. As the temperature of the heated surface rises, the warming effect is felt throughout the air and surrounding areas. Reflective heaters are great for open or large rooms, and actually save you energy by warming objects and not the entire room.

Reflective heating is both safe and healthy– it produces no odors, chemicals, or fumes, and doesn't stir up dust. As a safety feature, the heater's exterior housing does not get as warm during use to reduce the risk of burns from anyone or anything touching the heater. Remarkably efficient, our heater uses less power to create the same amount of heat as traditional heaters. Equipped with safety tip-over switch and overheat auto-off, the NewAir reflective heater is safe and reliable.

SPECIFICATIONS


| | |
|-------------------|--|
| Voltage Rating | 120 V (60Hz) |
| Power Consumption | 800W on High, 400W on Low |
| Unit Size | 14.5 in. (W) x 13.5 in. (D) x 34 in. (H) |
| Unit Weight | 6.5 lbs |

PRODUCT DIAGRAM




* Diagram may differ slightly from actual product.

ASSEMBLY



1. Remove the heater body and base from the box. Remove the packaging materials and keep for future storage.
2. Slide the neck of the heater head into the column connected by the cord, so that the holes in the neck align with the holes in the column.



3. Insert and tighten the screws with a Philips screwdriver.



4. Attach the base to the heater body by screwing on the fastening screw.

OPERATING INSTRUCTIONS

Control Panel Operation

1. Place the heater on a firm, level surface and plug into a grounded 120V 60Hz power outlet.
2. Press the ON/OFF button to turn on the heater. POWER indicator light and HIGH indicator light are working.


LOW: heating up to 400W
HIGH: heating up to 800W

3. Timer: The heater is equipped with a 0.5 to 4 hour timer. To select the desired length of operation, press the TIMER button repeatedly. Add up the lit indicator lights for the total number of hours. The heater will automatically shut off after the set time has elapsed.

Note:

0.5H: 30 minutes
1H: 1 hour
2H: 2 hours
4H: 4 hours


5. Swing: Press the OSCIL button and the heater head will oscillate 90° from right to left. The indicator light will turn on. Press the OSCIL button again to stop oscillation. The indicator light will turn off.



CONTROL PANEL

Remote Control Operation

The remote control can be used to perform all the operations that can be performed from the control panel.



REMOTE CONTROL

Height Adjustment: Press in the height adjustment button and simultaneously pull the sliding column up to the desired height. Release the height adjustment button to set. To

reduce the height, press in the height adjustment button and simultaneously push the sliding column down. Release the button to set.

Heater Head Adjustment: Grasp the reflection hood and gently tilt forward or backwards. The unit will click into the different positions. (Notice: When adjusting the heater head, the heater must be turned off to ensure safety.)

NOTE: A tip-over safety protection switch is installed at the bottom of the heater. When the heater is not placed horizontally, laid down or lifted up, it stops operating to ensure safety. After placing the heater upright it will resume operation.

NOTE: For safety, if the heater's internal temperature rises above a certain point, the heater is designed to automatically shut off. To restart the heater in this situation:

1. Push the power button to ON/OFF.
2. Unplug the power cord from the outlet and allow the heater to cool for at least 10 minutes.
3. Plug the power cord back into the outlet. Use the control panel to select the desired settings.

WARNING: It is normal for the power cord to feel warm to the touch; however, a loose fit between the outlet and the plug may cause overheating of the plug. If this occurs, try inserting the plug into a different outlet. Contact a qualified electrician to inspect the original outlet for damage.

MAINTENANCE

1. Unplug the unit and let it cool completely.
2. To keep the heater clean, the outer shell may be cleaned with a soft, damp cloth. You may use a mild detergent if necessary. After cleaning, dry the unit with a soft cloth.
CAUTION: DO NOT let liquid enter the heater.
3. **DO NOT** use alcohol, gasoline, abrasive powders, furniture polish, or rough brushes to clean the heater. This may cause damage or deterioration to the surface of the heater.
4. **DO NOT** immerse the heater in water.
5. Wait until the unit is completely dry before use.

STORAGE

Store the heater in a cool, dry location when not in use. To prevent dust and dirt build-up, use the original packaging to repack the unit.

TROUBLESHOOTING

If the heater will not operate, please check the following before seeking repair of service:

1. Check if the power cord is plugged into an electrical outlet, if not, plug in.
2. Check if electricity to the main fuse is working.
3. Check if the heater is set to ON by confirming the light on the control panel is lit. If not, press the POWER button to turn on the unit.
4. Check if the heater is on a level surface. If the tip-over safety switch is not pushed in, the heater will not run.

WARRANTY

THIS WARRANTY DOES NOT COVER:

- 1) Damage, accidental or otherwise, to the unit while in the possession of a consumer not caused by a defect in material or workmanship.
- 2) Damage caused by consumer misuse, tampering, or failure to follow the care and special handling provisions in the instructions.
- 3) Damage to the finish of the case, or other appearance parts caused by wear.
- 4) Damage caused by repairs or alterations of the unit by anyone other than those authorized by Soleus International Inc.
- 5) Freight and Insurance cost for the warranty service.